

Mop up or absorb the residual cleaner solution and suds with a clean, disposable, absorbent pad until the surface appears dry. This cleaning should remove any residual dirt, dust, grime, or other absorbent materials left on the surface during the first wash.

(b) *First rinse.* Rinse off the wash solution with 1 gallon of clean water per square foot and capture the rinse water. Mop up the wet surface with a clean, disposable, absorbent pad until the surface appears dry.

(c) *Second wash.* Follow the procedure in § 761.372(a).

(d) *Second rinse.* Follow the procedure in § 761.372(b).

§ 761.378 Decontamination, reuse, and disposal of solvents, cleaners, and equipment.

(a) *Decontamination.* Decontaminate solvents and non-porous surfaces on equipment in accordance with the standards and procedures in § 761.79(b) and (c).

(b) *Reuse.* A solvent may be reused so long as its PCB concentration is <50 ppm. Decontaminated equipment may be reused in accordance with § 761.30(u). Store solvents and equipment for reuse in accordance with § 761.35.

(c) *Disposal.* Dispose of all solvents, cleaners, and absorbent materials in accordance with § 761.79(g). Dispose of equipment in accordance with § 761.61(a)(5)(v)(A), or decontaminate in accordance with § 761.79(b) or (c). Store for disposal equipment, solvents, cleaners, and absorbent materials in accordance with § 761.65.

Subpart T—Comparison Study for Validating a New Performance-Based Decontamination Solvent Under § 761.79(d)(4)

SOURCE: 63 FR 35473, June 29, 1998, unless otherwise noted.

§ 761.380 Background.

This subpart provides self-implementing criteria for validating the conditions for use in performance-based decontamination of solvents other than those listed in § 761.79(c)(3) and (c)(4). Any person may use this subpart for validating either a chemical formulation or a product with a

trade name whether or not the constituents of the product are proprietary.

§ 761.383 Applicability.

Use the self-implementing decontamination procedure only on smooth, non-porous surfaces that were once in contact with liquid PCBs. Decontamination procedures under this subpart shall exactly parallel § 761.79(c)(3) and (c)(4), except that the procedures described in § 761.79(c)(3)(iii) and (c)(3)(iv) and (c)(4)(iii), (c)(4)(iv) and (c)(4)(vii) may be revised to contain parameters validated in accordance with this subpart.

§ 761.386 Required experimental conditions for the validation study and subsequent use during decontamination.

The following experimental conditions apply for any solvent:

(a) *Temperature and pressure.* Conduct the validation study and perform decontamination at room temperature (from ≥ 15 °C to ≤ 30 °C) and at atmospheric pressure.

(b) *Agitation.* Limit the movement in the solvent to the short-term movement from placing the contaminated surface into the soak solvent and from removing the surface from the soak solvent.

(c) *Time of soak.* Soak the surface for a minimum of 1 hour.

(d) *Surface conditions for the validation study.* Prior to beginning the validation study, ensure that there are no free-flowing liquids on surfaces and that surfaces are dry (i.e., there are no liquids visible without magnification). Also ensure that surfaces are virtually free from non-liquid residues, corrosion, and other defects which would prevent the solvent from freely circulating over the surface.

(e) *Confirmatory sampling for the validation study.* Select surface sample locations using representative sampling or a census. Sample a minimum area of 100 cm² on each individual surface in the validation study. Measure surface concentrations using the standard wipe test, as defined in § 761.123, from which a standard wipe sample is generated for chemical analysis. Guidance for wipe